


ILLUSTRATION



- 1.BODY
- 2.HOLDER
- 3.FIXING CLIP

- 4.LED INDICATOR
- 5.SWITCH
- 6.MICRO USB SOCKET

ENVIRONMENTAL PROTECTION



Waste electrical & Electronic equipment regulations requires that any of our products showing this marking must not be disposed of with other household or commercial waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate any such products from other waste types and recycle it responsibly at your local facilities.

eurolux
Lighting your way

Mini Fan



PRODUCT CODE

F87

Cape Town - 9 Racecourse Road, Milnerton, 7441
Johannesburg - 10 Milkyway Avenue, Linbro Business Park, Sandton, 2065
email: admin@eurolux.co.za web: www.eurolux.co.za

Please read instructions before commencing installation and retain for future reference.

IMPORTANT SAFEGUARDS

F87 - attachments:

If the external flexible cable or cord of this Fan is damaged, it should be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard. To ensure that you get maximum longevity and maximum use out of your Fan, please observe the following safety instructions.



Electrical products can cause death, injury, or damage to property. Installation of the Fan must be carried out by a qualified electrician, in accordance with SANS 10142. On completion of installation, ensure that the Certificate of Compliance is updated.

- Before connecting the Fan, ensure that voltage indicated on the rating label Corresponds with the mains voltage in your home.
- This Fan is checked in full for conformity to the quality standards and safety requirements.
- The manufacturer / supplier is not responsible for any damage of properties and persons, caused by the incorrect use or installation of the Fan.

IMPORTANT:

- Tampering with this Fan, will invalidate your warranty.
- Please check whether the connection of the power cord is safe and reliable before use.
- Always ensure that the mains supply voltage is correct.
- Choking hazard: May contain small parts. Keep away from children.
- Do not insert your fingers or any part of your body into the electrical contact and sockets of this product whilst it is connected to the electrical supply.
- Item may vary slightly from the picture on the carton.

SPECIFICATIONS

- **Battery:** 3.7V 1.8Ah Lithium-ion Battery
- **Charge time:** 6 - 8 hours
- **Fan Duration:**
 - 1.5 hours / high speed
 - 2.5 hours / medium speed
 - 4 hours / low speed
- **Dimension:** 153mm x 113mm x 200mm
- **Voltage:** 220-240V 50Hz

OPERATION

IMPORTANT:

- Please read this manual carefully before you start using this Fan in full charge.
- Make sure that the voltage is correct before plug-in.
- Charge the Fan when light goes dim.
- Turn off the switch when the Fan is not in use.
- The efficiency may decrease if the Fan is used or charged when temperature is below 32F (0°C) or above 104F (40°C).
- To avoid damage to the Fan, please do not use any other than the specified battery.
- To avoid electrical shock, please do not open the Fan unless by a qualified person.

How to recharge

- Make sure the voltage is correct before charging Fan.
- Plug into the mains electrical supply.
- Charge the Fan periodically for at least 8 hours while not in use for over 3 months to prolong the battery life.

Operation:

- Press FAN button consecutively for low speed / medium speed / high speed / off